



Warning:



Must be installed by a certified electrician.

Consult your owners manual.

Disconnect power and release all pressure from system prior to performing maintenance or changing the pressure switch.




PUSH/PULL PRESSURE SWITCH

*For Use On Most 125 PSI
Air Compressors
Four Port With 1/4" NPT*

6-5610 Instruction Manual:

- 1) Install the push/pull type pressure switch correctly with technical data on product itself and wiring diagram;
- 2) push the red button down when using;
- 3) To maintain the air compressor, the pressure switch will automatically shut off if the pressure reached 125PSI, and will also automatically start if the pressure is less than 95PSI;

Technical Data	6-5610
Type	Push-Pull
Ports	Four (4)
Pressure Range	20-175 PSI
Pressure Setting	95-125 PSI
Rated Current	20 Amp
Rated Voltage	115 V
Frequency	60 Hz
Max. Ambient Temp.	40°C/104°F
Protection Degree	IP20
Certification	CE, UL, TUV, RoHs



6-5610 wiring diagram

